



OPERATION MANUAL

WAYFINDER V7000

DIGITAL VEHICLE COMPASS



CONGRATULATIONS!

You have purchased one of the most sophisticated compasses available for use in a vehicle. The Wayfinder V7000 is a valuable tool for your vehicle, utilizing technology to make a digital compass easy and informative to use, while incorporating patented magnetic sensor technology to give you accurate compass headings. PNI's magnetic sensor technology electronically measures your vehicle's magnetic field and calibrates for inaccuracies mathematically with its built-in microprocessor. The result is unequalled compass performance in a vehicle environment.

Features



- Uses patented magnetic sensor technology, same as the built-in compasses in GM, Ford, and Chrysler vehicles.
- 3-Mode compass shows direction with compass rose, 8 cardinal points, and 1° numeric digits.
- Altimeter displays the current altitude in feet or meters.
- Barometer displays barometric pressure and up/down trends to determine weather patterns.

FEATURES

- Weather forecast predicts sun, cloud, or rain based on barometric pressure .
- “Auto-Integrate” circuitry, automatically turns the unit on (when engine is turned on and unit is used with 12-volt adapter) or off when no magnetic field changes have been sensed for 10 minutes.
- Indicates inside temperature, outside temperature and ICE alert in either Fahrenheit or Celsius.
- Declination adjustment allows the unit to be set to either true or magnetic north.
- Bearing point stores compass heading in memory to stay on desired course.
- Programmable backlight auto shut-off feature.
- Photo sensor feature turns the backlight on or off depending on the amount of ambient light.
- Distortion indicator alerts you when magnetic interference from outside sources, such as steel from a bridge or overpass, is affecting compass accuracy.
- Holographic LCD improves brightness and contrast while removing glare.
- 2-year extended warranty.

CONVENTIONS USED IN THIS MANUAL




1. The LCD icons are written in all capital letters with quotes around them.
2. Buttons used in procedures are presented as button icons.
3. Procedures are organized so that the action to perform follows the step number, and result of that action is indented.
4. “Press” means press and release a button in less than 2 seconds.
5. “Hold” means press and hold the button for at least 2 seconds, or until a display appears.
6.  Indicates a warning or important information
7.  Indicates optional equipment available at additional cost.
8. The 3 horizontal lines of display on the right side will be referred to as line 1 through 3 starting at the top.




CONTENTS

Display and Buttons	5	Barometer mode	25
Installation	8	Weather forecast display	26
Step 1: Installing the battery	8	Temperature mode	26
Step 2: Installing the 12-volt adapter	9	ICE alert feature	27
Step 3: Installing the external temperature sensor	9	Altitude mode	28
Step 4: Mounting the unit	12	Alt.Set mode	29
Programming and Operation	16	Optional Accessories	30
Calibration mode	16	Declination Angle Map	31
Declination mode	18	General Specifications	32
Backlight mode	21	Frequently Asked Questions	33
Photo sensor feature	22	Service and Replacement	37
Bearing mode	23	Warranty	39

DISPLAY AND BUTTONS



FRONT



BACK

DISPLAY AND BUTTONS

The Wayfinder V7000 displays direction of travel in three different formats: (1) cardinal points, (2) numeric digits (325°, 330°, etc.), and (3) compass rose. The eight cardinal points of a compass (N, NE, E, etc.) give you the general direction. The numeric digits show your exact direction to the nearest 1°. The compass rose arrow points in the direction you are heading relative to north.

The slow flashing of the degree symbol in line 2 indicates when magnetic interference is compromising compass accuracy or when a battery has been installed.

Buttons

ON/OFF button

Press **ON/OFF** or any other button to turn compass on and hold **ON/OFF** to turn compass off. Once on, pressing **ON/OFF** toggles the backlight on or off.

STEP button

Press **◀STEP▶** in normal display mode to toggle between displaying “IN TEMP” (inside temperature), “OUT TEMP” (outside temperature), and “BEARING” (bearing point). Press **◀STEP▶** in programming mode to advance through the values to select.

DISPLAY AND BUTTONS

MENU button

Press **MENU** to advance through programming menu options “CALIB” (calibration), “dECL” (declination), “LIGHt” (backlight), “bEAR” (bearing point), “bARo” (barometer), “tEMP” (temperature) and “ALt” (altimeter) and to exit a programming menu.

ENT button

Press **ENT** in normal display mode to toggle between barometric pressure, altitude, and weather forecast. Press **ENT** in programming mode to store a displayed value.

ALT.SET button

Press **ALT.SET** as a quick reset for altitude. It resets the altitude from the currently displayed altitude to the stored altitude.

INSTALLATION

Step 1: Installing the battery

The Wayfinder V7000 uses a CR123 Lithium type battery, installed according to the diagram on the inside of the battery compartment. Push the battery straight down into the compartment, not at an angle. To remove, open the battery compartment and tap the back of the unit against the palm of your hand and the battery will come out.

Once the battery is inserted, the unit will go through a quality test. If the display becomes stuck, remove the battery, wait for approximately one minute, and then reinsert the battery.

If the battery is the only power source, whenever the battery is changed or removed, the Wayfinder V7000 must be recalibrated and all previous feature settings must be reset. With the 12-volt adapter or the hardwire kit installed, the battery may be removed or changed without affecting any settings.

The Wayfinder V7000 has an auto shut-off feature. When no magnetic field change has been detected for approximately 10 minutes, the compass automatically switches off and saves all settings. Note: The unit also switches on automatically if used with the 12-volt adapter (see next section).

INSTALLATION

Step 2: Installing the 12-volt adapter

Installing the 12-volt adapter is optional, but highly recommended. Insert the small end into the jack marked “POWER,” located on the back of the compass, and plug the large end into your cigarette lighter receptacle.

*** The Wayfinder V7000 switches on automatically when it senses the engine is on. This feature is operational only when the 12-volt adapter is used or the optional hardwire kit is installed.**

! The photo sensor feature of the Wayfinder V7000, which allows the backlight to turn on automatically, is

operational only when the 12-volt adapter is used or the optional hardwire kit is installed.

! Since cars do not always have constant power supplied to the lighter receptacle, you must keep a battery in the Wayfinder V7000 at all times to allow the unit to keep memory settings.

*** A 15-foot (4.5m) hardwire kit is available at additional cost. See *Optional Accessories*.**

INSTALLATION

Step 3: Installing the external temperature sensor

The Wayfinder V7000 has a built-in internal temperature sensor designed to measure the temperature inside the vehicle at the windshield (“IN TEMP”).

The Wayfinder V7000 also includes a wire temperature tether designed to measure the temperature outside the vehicle (“OUT TEMP”). The sensor end of the tether must be mounted outside of the passenger compartment, away from engine heat or direct sunlight, in a place where there is natural airflow to the sensor, such as in the


grill area or door jamb. It is best to adhere the sensor on a surface that is least conductive to heat -- such as on a rubber or plastic surface as opposed to the steel body of the vehicle. The temperature from this sensor is displayed as “OUT TEMP.”


Every vehicle is different, making it impossible to list all possible sensor locations. Use your best judgment to select the site for the temperature sensor and experiment with various locations, if necessary.


INSTALLATION

To install the external temperature sensor:

1. Insert the connector end of the tether into the jack marked “TEMP,” located on the back of the compass. The jack is keyed for easy identification.
2. Adhere the sensor end of the tether outside of the passenger compartment. Make sure the mounting surface is free of oil and dirt.
3. Use the included retainer clips to secure the temperature tether to the windshield or dashboard (optional).

 If the temperature sensor is not plugged in and **<STEP>** is toggled to “outside temperature” display, the message “PLUG IN TEMP CABLE” will scroll in the upper right corner three times, then will display “_ _ _ °F.”

 Do not leave the unit in a parked vehicle that is likely to be exposed to extremely hot or cold temperatures.


 * A 30-foot (9m) temperature sensor is available at additional cost. See *Optional Accessories*.

INSTALLATION

Windshield Mounting:

1. Install the suction cups into the mounting bracket by sliding them into their holes (if not pre-installed).
2. Do not loosen the screw at the pivot point where the two-piece bracket is assembled (see illustration next page).
3. Hold the base plate where the suction cups are attached in one hand and the compass shaped holder in the other.
4. Pull the sections apart to disengage teeth and swivel to desired angle while still maintaining the space between the bracket teeth. Release once desired angle is achieved and check that the teeth have locked securely into place.
5. With the battery and/or 12-volt adapter installed, slide the unit all the way into the compass shaped holder until you hear/feel the “click” when the locking fingers slip into place and press the suction cup base firmly against the windshield. If necessary, apply a thin layer of petroleum jelly to improve suction cup grip.
6. Insert the small plug end of the 12-volt adapter into the jack marked “POWER”,

INSTALLATION




INSTALLATION

located on the back of the compass and plug the large plug end into your cigarette lighter receptacle. (optional)

Step 4: Mounting the unit

- Choose a place on the windshield that will not obstruct the driver's view and is within reach so the buttons are easy to push. Make sure the windshield surface is clean. Once installed, the face of the compass must be pointing toward the rear of the vehicle.
- The unit can be tilted up or down a maximum of 20° from horizontal plane (road level). If tilted more than $\pm 20^{\circ}$, the heading information after calibration may not be accurate. The selected angle from horizontal plane must stay fixed after calibration for the heading to remain accurate (see illustration next page).
- The accuracy of the Wayfinder V7000 will be diminished by a strong magnetic field, such as that found in proximity to an audio speaker. It is recommended that the unit be mounted 5 or more inches (13 cm) away from stereo speakers.

INSTALLATION



! Do not leave the Wayfinder V7000 in a parked vehicle that is likely to be exposed to extremely hot or cold temperatures.

! Adjustment of this bracket does not require the use of a screwdriver. Please do not remove the screw from the pivot point of the bracket, the internal parts are small and can easily be lost.

PROGRAMMING AND OPERATION

Calibration Mode

Calibration is the process whereby the Wayfinder V7000 separates the earth's magnetic field from other magnetic fields. Without calibration, the unit thinks the entire magnetic field it is reading is from the earth and therefore displays inaccurate compass readings.

Calibration Guidelines

1. The Wayfinder V7000 needs to be calibrated (1) when used for the first time in a vehicle, (2) when moved to a different location in the same vehicle, (3) when moved to a different vehicle, or (4) when the battery is removed if neither the 12-volt adapter nor the hardwire kit is installed.
2. The Wayfinder V7000 requires recalibration when there has been a change to your vehicle, such as the installation of a new stereo or when the degree symbol on line 2 flashes continuously.
3. If you intend to operate your Wayfinder V7000 with the temperature tether installed, then it should be calibrated after tether installation has been completed.

PROGRAMMING AND OPERATION

4. If you drive with your headlights and stereo on, turn these on prior to calibration.

Calibrating the unit

To begin calibration, press **MENU** to toggle through the programming options until “CALib” and “SEt” display on screen.

1. Press **<ENT>**.

“PrESS StEP to StArt” *displays*.

If **MENU** is pressed now, the unit returns to normal display.

2. Press **<STEP>**.

“turn ONCE PrESS Ent to End” *displays*.

Turn vehicle in one complete circle in either direction. Circle size does not matter. Take at least 20 seconds to complete the circle.

3. Press **<ENT>**.

“dONE” *flashes once, and the unit returns to normal display mode. If the degree symbol on line 2 flashes after calibration, repeat the calibration process. A flashing degree symbol indicates magnetic distortion. See the Frequently Asked Question section for more information.*

PROGRAMMING AND OPERATION

Declination Mode

Declination, also called magnetic variation, is the difference between true and magnetic north, relative to a point on the earth. It is measured in degrees to the east or west of true north. The Wayfinder V7000 corrects for declination electronically. Correcting for declination is accomplished by storing in the correct declination angle, and then changing the heading reference from magnetic north to true north (see following section). Declination angles vary throughout the world, and change very slowly over time. See page

31 for a declination angle map for the United States. For the greatest possible accuracy, go to the National Geophysical Data Center web page below to get the declination angle based on your latitude and longitude:

www.ngdc.noaa.gov/cgi-bin/seg/gmag/fldsnt1.pl

If you do not know your exact latitude and longitude in the USA, go to the web page below to get latitude and longitude from your city and state or from your zip code:

www.census.gov/cgi-bin/gazetteer

Outside the USA try the Getty Thesaurus at:
www.getty.edu/research/tools/vocabulary/tgn/

PROGRAMMING AND OPERATION

To enter a declination angle

Press **MENU** to toggle through the programming options until “dECL” and “SET” display on screen.

1. Press **ENT**.
“_ _ °” displays on line 2 and “W” or “E” displays on the compass rose.
2. Press **STEP**.
To toggle between flashing “W” or “E” on compass rose.
3. Press **ENT**.
To select “W” or “E.”

The 10s position on line 2 starts flashing.

4. Press **STEP**.
Display changes from “_ _ °” to “00°” and the 10s position zero is flashing.
*Continue to press **STEP** until the correct number displays.*
5. Press **ENT**.
To select the 10s digit, which stops flashing.
The 1s digit begins flashing.
6. Press **STEP**.
To advance the 1s digit.

PROGRAMMING AND OPERATION

Continue to press **(STEP)** until the correct number displays.

7. Press **(ENT)**.

To select the 1s digit, which stops flashing.

Press **(MENU)** to exit to normal display mode.

To select between true or magnetic north:

Note: The proper declination angle must first be stored as indicated in the previous section.

1. Press **(MENU)** to toggle through the programming options until “dECL” and “SEt” display on screen.
2. Press **(STEP)** to select between true or magnetic north.

The declination icon in the upper left corner appears to indicate true north or disappears to indicate magnetic north.

PROGRAMMING AND OPERATION

Backlight Mode

The Wayfinder V7000 has a programmable backlight auto shut-off feature when operating on battery power. The default auto shut-off value is 10 seconds, which means that after the backlight has been on for 10 seconds, it will automatically turn off. Other auto shut-off values include 30, 60, 180, and 00 seconds. The auto shut-off feature can be disabled, by selecting “00”, which means that the backlight will stay on until it is manually turned off, or when the unit shuts off after 10 minutes of no magnetic change. Since

the backlight uses significantly more power than the unit itself, it is recommended that the backlight be turned off when not needed. Alternatively, use the 12-volt adapter to save battery life. The backlight can be turned off at anytime by pressing **ON/OFF**.

To change the backlight auto shut-off value

Press **MENU** to toggle through the programming options until “LIGHT” and “SEt” display on screen.

1. Press **ENT**.

The first numeric time value displays in line

PROGRAMMING AND OPERATION

2 and “SEC” in line 3.

2. Press **◀STEP▶**

To advance through the values of 10, 30, 60, 180 and 00 seconds respectively.

3. Press **MENU**.

To select value and exit to normal display mode.

! If the 12-volt adapter or optional hardwire kit is installed, the photo sensor feature disables the time value for backlight shut-off.

Photo sensor feature

The Wayfinder V7000 comes equipped with a photo sensor that turns the backlight on or off depending on the amount of ambient light it senses when the 12-volt adapter is plugged in or the optional hardwire kit is installed. The backlight turns on when the unit senses darkness and turns off under the following conditions:

- when the unit senses light again
- when **ON/OFF** is pressed
- when no magnetic field change has been detected for approximately 10 minutes

PROGRAMMING AND OPERATION

Bearing Mode

Quick method of entering a bearing point

Press **(STEP)** until “b_ _ _ °” or the last entered bearing value appears in line 1.

1. Align your vehicle so the numeric heading to be stored as a bearing point appears in line 2.
2. Hold **(STEP)** to store bearing.

The bearing value will display on line 1. A flashing arrow corresponding to the stored bearing value will appear on the compass rose display whenever the direction of travel differs from the stored bearing.

To erase bearing point, see long method.

Long method of entering a bearing point

Press **(MENU)** to toggle through the programming options until “bEAR” and “SEt” display on screen.

1. Press **(ENT)**.
Either “_ _ _ °” or the last entered bearing value appears in line 1 with the 100s digit flashing.
*If **(STEP)** is held now, the last entered bearing point is erased.*
2. Press **(STEP)** to enter a bearing point.
100s digit advances. Continue pressing until correct digit displays.

PROGRAMMING AND OPERATION

3. Press **◀ENT▶**.

*To store selected digit in 100s position and 10s digit flashes. Press **◀STEP▶** until correct digit displays then press **◀ENT▶** to store. The 1s digit now flashes. Press **◀STEP▶** to advance digit until correct one displays. Press **◀ENT▶** to store then press **MENU** to exit.*

The bearing value will display on line 1. In bearing display mode, a flashing arrow representing the stored bearing value will appear on the compass rose if the direction of travel differs from the stored bearing.

To view a stored bearing

Press **◀STEP▶** in normal display mode to toggle between the various display options until the bearing point value appears.

PROGRAMMING AND OPERATION

Barometer mode

The Wayfinder V7000 contains a pressure sensor capable of detecting pressure changes caused by weather conditions, altitude changes, and cabin pressure. The barometer reading reports the same type of value that is reported by most weather reports, namely sea-level pressure.

Press **◀ENT▶** in normal display mode to toggle between the various display options until the “BAROMETER” indicator is on. Barometric pressure is updated every second and appears numerically on the display with an up/down trend arrow. The trend arrow indicates

whether the pressure has increased or decreased over the last hour. The unit stores pressure data continuously, even when off.

To select between “mb” (millibars) or “inHg” (inches of mercury)

Press **MENU** to toggle through the programming options until “bAro” and “SEt” display on screen.

1. Press **◀STEP▶** to toggle between the “mb” or “inHg” indicators


*When the scale you want is flashing, press **MENU** to select and exit to normal display mode.*

PROGRAMMING AND OPERATION


Weather Forecast Display

The Wayfinder V7000 provides 3 weather forecasts (Sun, Cloud, or Rain) based on a 24-hour change in in barometric pressure. Therefore, the unit requires 24 hours of data before it is able to predict the weather.

Press **<ENT>** in normal display mode to toggle between the various display options until “SUN”, “CLOUD”, or “rAIN” appears on line 3. If not enough pressure data is available to provide a forecast, the message “Not EnouGH PrESSurE dAtA” scrolls on line 3.

 **Barometer and weather forecast readings are affected by altitude and cabin pressure changes. Please refer to the *Frequently Asked Questions* section for more information.**

Temperature mode

 **If the temperature sensor has not been properly installed prior to **<STEP>** being toggled to “OUT TEMP,” the message “PLUG IN tEMP CABLE” will scroll three times in the upper right corner, then will display “_ _ _ °F.”**

Press **<MENU>** to toggle through the program-

PROGRAMMING AND OPERATION

ming options until “tEMP” and “SEt” display on screen.

1. Press **<STEP>**.

*To toggle between “°C” or “°F.” When the scale you want is flashing, press **MENU** to select and exit to normal display mode.*

! **Do not leave the Wayfinder in a parked vehicle that is likely to be exposed to extremely hot or cold temperatures.**

ICE alert feature

When the outside temperature sensor is installed, the ICE alert feature can sense

and warn you if the temperature drops to 35°F (1°C). When this happens, the unit will automatically switch to “TEMP” mode and “ICE” will flash for 20 seconds on line 2 and the temperature will display on line 1.

The V7000 displays temperature readings between 1°F and 158°F (-17°C to 70°C). If the temperature falls below 1°F (-17°C), the display will flash “UNDER 1°F” (or “UNDER -17°C”) until the temperature rises above the minimum. Similarly, If the temperature rises above 158°F (70°C), the display will flash “PLUS 158°F” (or “PLUS 70°C”) until the temperature drops below the maximum.

PROGRAMMING AND OPERATION

Altitude mode

Press **◀ENT▶** in normal display mode to toggle between the various display options until the “ALTITUDE” indicator is on. The altitude appears numerically with an up/down trend arrow, which indicates whether the altitude is increasing or decreasing as you travel.

You must calibrate the altimeter from a location with a known altitude, such as your house, when the unit is used for the first time in a vehicle. For optimum performance, it is best to recalibrate as often as possible (see Alt.set mode next page).

Press **MENU** to toggle through the programming options until “ALT” and “SET” display on screen.

1. Press **◀STEP▶** to toggle between “ft” (feet) or “m” (meters).
2. Press **◀ENT▶** to store “ft” or “m.”

Either “_ _ _ _ _” or the previous altitude displays in 5 digits on line 3 next to unit of measure selection and the farthest left digit starts flashing.

PROGRAMMING AND OPERATION


3. Press **<STEP>** to advance the first flashing digit.

4. Press **<ENT>** to select value.

The second digit from the left starts flashing.

*When all 5 digits have been assigned values, press **<MENU>** to exit to normal display mode.*

Alt.set mode

 Please refer to the *Frequently Asked Questions* section for altimeter reading.

To reset altitude back to the value set in altitude mode, press **<ENT>** to toggle line 3 display to altitude, then do the following:

1. Hold **<ALT.SET>**.


The set altitude value now displays on line 3.

OPTIONAL ACCESSORIES

- * A 15-foot (4.5m) hard-wire kit is available for an additional charge by calling our customer service department at (888) 422-6672 from within the U.S.A., (707) 566-2260, or by e-mail at customerservice@pnicorp.com. Please seek the assistance of an automotive accessory installer to ensure proper installation in your specific vehicle.
- * A 30-foot (9m) temperature sensor tether is available for an additional charge by calling our customer service department at (888) 422-6672 from within the U.S.A., (707) 566-2260, or by e-mail at customerservice@pnicorp.com.

DECLINATION ANGLE MAP

Figure A
Declination angles
for the United
States



GENERAL SPECIFICATIONS

- **Battery life:**
3,600 hours without backlight, 140 hours with constant backlight usage.
- **Operating temperature range (°F/°C):**
14°F to 140°F / -10°C to 60°C
- **Storage temperature range (°F/°C):**
-40°F to 185°F / -40°C to 85°C
- **Temperature resolution/accuracy:**
1°F / ±5°F within operating range
(1°C / ±2°C)
- **Altimeter function (ft/m):**
-1,500 ft to 19,995 ft / -455 m to 6045 m
- **Altimeter resolution/accuracy:**
5 ft / ± 75 ft at constant air pressure
(1m / ±23 m)
- **Barometer function (mb/inHg):**
300 to 1,100mb / 8.90 to 32.40 inHg
- **Barometer resolution/accuracy:**
1mb or 0.03inHg / ±1.5 mb or ±0.044 inHg

FREQUENTLY ASKED QUESTIONS

How does the Wayfinder V7000 work?

The Wayfinder V7000 uses a patented magnetic sensor technology that was developed by PNI Corporation for the U.S. military. This technology is called *magneto-inductive* and is the largest advance in compass technology since the fluxgate was invented 60 years ago. The earth generates a magnetic field, and through a mathematical calculation, compass heading is determined. The magneto-inductive technology is able to electronically sense the difference in the earth's field from your vehicle's magnetic field. The Wayfinder V7000's microprocessor electronically subtracts out your vehicle's mag-

netic fields, displaying highly accurate compass readings. Magneto-inductive sensor technology has many advantages over other technologies, including better performance, less power consumption, and lower cost. These advantages have made magneto-inductive sensor technology the choice for many high profile compass applications including GM, Ford, and Chrysler automobiles, Polaris jet skis, Bayliner boats, and Timex watches.

Where can the Wayfinder V7000 be used?

The Wayfinder V7000 can be used in any type of vehicle, including cars, trucks, vans, SUVs, off-road vehicles, boats, and RVs.

FREQUENTLY ASKED QUESTIONS

What does it mean when the degree symbol on line 2 is flashing slowly?

This indicates magnetic distortion. Many things generate external magnetic fields causing compass inaccuracy, including metal and electronics. The Wayfinder V7000 senses any significant change in magnetic fields and the associated magnetic distortion that occurs. The degree symbol may flash briefly when driving over a bridge, under an overpass, over railroad tracks, within close proximity to a strong magnetic field, or when the battery is installed. Once the vehicle has moved away from the source of the magnetic field or has

been calibrated, the Wayfinder V7000 will be accurate. If the degree symbol flashes continuously or immediately after calibration, the unit needs to be calibrated again, where there is less magnetic interference.

How can I maximize weather forecast and altitude accuracy?

The Wayfinder V7000 sensor cannot determine the specific cause of a pressure change, such as if the change is due to weather conditions, altitude changes, or cabin pressure. Therefore, for barometer and weather forecast readings to be most accurate, the effect of altitude and cabin pressure must be mini-

FREQUENTLY ASKED QUESTIONS

mized. Similarly, the effect of weather condition and cabin pressure changes must be minimized in order for altitude readings to be most accurate.

Will my weather forecast and barometric pressure readings be accurate if my altitude is changing?

The Wayfinder V7000 predicts the weather based on changes in pressure. In addition to changes in weather and cabin pressure, pressure also varies depending on altitude. A change of ± 50 ft (15m) in altitude can make the weather forecast inaccurate. Therefore, to obtain an accurate weather forecast when

you are changing altitude, make sure you recalibrate the pressure sensor for that altitude. When recalibrating for a new altitude, weather forecasts may not be accurate for 24 hours. As a guideline, we recommend using the altitude function while traveling and the barometer and weather forecast function while the vehicle is stationary.

Why would my altimeter reading change from one day to another when my vehicle is parked at the same location?

Even slight weather changes can cause altitude changes of up to 50 feet (15m), and extreme weather can cause changes of up to

FREQUENTLY ASKED QUESTIONS

200 feet (60m). Use the Alt.set feature as often as possible and no less than once a day to recalibrate altitude and reset barometric readings to sea-level pressure adjusted for your altitude.

What is vehicle cabin pressure?

Changes in vehicle cabin pressure, caused by opening or closing doors or windows or turning ventilation fans on or off, alters the barometric pressure. A change of up to ± 50 feet (15m) in altitude can occur from cabin pressure changes. To get a more accurate reading, it is recommended that you close your windows when traveling at highway speeds and

set your ventilation system to recirculate inside air instead of bringing in outside air if the fan is on. Pressing **ALTSET** every morning will reset the altimeter to its original setting.

How can the bearing point feature help me?

Following the position of the sun and spotting familiar landmarks can give you an idea of what direction you are heading in during the day. This differs at night or on a foggy day when the sun and landmarks are obscured. By setting a bearing point and monitoring your headings, you can be far more certain of direction, even on unfamiliar roads.

SERVICE AND REPLACEMENT

Customer Service

Please e-mail customer service department at customerservice@pnicorp.com or call us between the hours of 8:00 a.m. and 5:00 p.m. (PST) Monday through Friday, with questions not answered here.

Replacement Service

For the fastest service, it is best to contact or return your unit to the place of purchase within 30 days of the purchase. If you wish to return the unit for replacement or repair to PNI Corporation, please do the following:

1. Obtain a return merchandise authorization (RMA) number by contacting PNI:

- By phone: (888) 422-6672 (toll-free within the U.S.A. only) or at (707) 566-2260 between 8:00 a.m. and 5:00 p.m. (PST).
 - By fax: (707) 566-2261
 - By e-mail: customerservice@pnicorp.com
2. Provide a proof of purchase, such as a mechanical reproduction or carbon copy of your sales receipt. If you send your original receipt, it cannot be returned. Proof-of-purchase must show printed date of purchase, model number, and place of purchase. There will be a charge for repair/replacement if no proof of

SERVICE AND REPLACEMENT

purchase is provided, or if it is past the warranty period.

Once you have acquired a RMA number, pack the unit securely to prevent damage in transit. If possible, use the original packing material and box. Be sure to send the entire product.

3. Ship prepaid and insured by way of a traceable carrier such as United Parcel Service (UPS), Roadway Parcel Service (RPS), or First Class Mail to avoid loss in transit.
4. Write the issued RMA number on the

outside of your package and send your proof-of-purchase and description of the problem to the following address:

PNI Corporation
5464 Skylane Boulevard, Suite A
Santa Rosa, CA 95403-1084

Type or print your name and address where the replacement should be delivered. After receipt of your documents and unit, a replacement unit will be sent to you. Please allow 2 to 3 weeks from receipt of your returned product to delivery of your replacement.

LIMITED WARRANTY; LIMITATION OF LIABILITY



The service and replacement section that follows is valid for products purchased and used in the U.S.A. and Canada only. For products purchased outside the U.S.A. and Canada, please contact your specific place of purchase for warranty information and/or service.

PNI Corporation manufactures its products from parts and components that are new or equivalent to new in performance and warrants to the original user that this product will be free of defects in workmanship and materials for two (2) years from the date of purchase. This warranty does not cover wear and tear due to normal use, or damage to the product as the

result of improper usage, neglect of care, alteration, accident or unauthorized repair.

If the product is found by PNI to be defective and you have provided proof of purchase acceptable to PNI, PNI's entire liability and your exclusive remedy for breach of warranty shall be that PNI, at its option, will replace or repair the product and return the replacement or repaired product to you at no charge, provided that you ship the product to PNI at your expense. PNI warrants the repaired or replaced product to be free from defects in material and workmanship for a period of: (i) ninety (90) days from the date it is shipped to you; or (ii)

LIMITED WARRANTY; LIMITATION OF LIABILITY




the period of time remaining on the original two (2) years warranty.

THE FOREGOING WARRANTY IS GIVEN IN LIEU OF AND PNI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESSED OR IMPLIED, IN FACT OR IN LAW, WITH RESPECT TO THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, (1) THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE, OR (2) THAT USE OF THE PRODUCT WILL BE UNINTERRUPTED AND ERROR FREE.

PNI shall have no liability for any indirect or

speculative damages (including, but not limited to, consequential, incidental and special damages) relating to the use of or inability to use this product, whether arising out of contract, negligence, tort, or under any warranty theory, or for infringement of any other party's intellectual property rights, irrespective of whether PNI had advance notice of the possibility of any such damages, including, but not limited to, loss of use, revenue or profit. In no event shall PNI's total liability for all claims regarding the product exceed the price paid for the product. PNI neither assumes nor authorizes anyone to assume for it any other liabilities.



PNI Corporation

www.pnicorp.com

11381 R02 1000242 VJ2-01