

Prior to printing, ensure that Page Scaling is set to "None" on your print dialog box. (To open the print dialog box, press CTRL+P.)

DOORSCOPE INSTALLATION TEMPLATE
CALCOMANI PARA INSTALACION DEL DOORSCOPE
ACTUAL SIZE TAMANO REAL

